

CHANGING A CYLINDER IN A KASON DOOR HANDLE

Removing the Old Cylinder

Step 1

Before you begin, the handle and cylinder must be functioning normally with the key. The key must be installed in the handle for this process.

Step 2

Begin by inserting the key. Turn the key 90 degrees clockwise (figure 1) while keeping the cylinder held down with the edge of your thumb.



29-750 Cylinder
Removal Tool

Step 3

While the key is turned 90 degrees and the cylinder pressed down, take the removal tool (29-750) with your other hand and place the open end of the tool over the top of the key and insert it into the indentation slots on the cylinder housing. (figure 2)



Step 4

Rotate the tool CCW (counter clockwise) about 1/4 turn while keeping pressure on the cylinder with your thumb and the key still turned. At this point the cylinder should “spring” out and be removable.

Installing the New Cylinder

Step 5

Insert the new cylinder into the handle bore until the retractable pin touches the opening. Insert and turn the key to retract the pin and use your thumb to depress the pin enough to completely insert the cylinder.

Step 6

Push the cylinder all the way in and rotate the entire cylinder until you hear a “click” of the pin extending into the cylinder bore. The cylinder should now be set. Test the key and cylinder to be sure it is working properly.